# 2019 -

# Part Number: PT747-33190 PT747-33191

#### **Kit Contents**

Item #	Quantity Reqd.	Description
1	1	Applique, RR Bumper

#### Hardware Bag Contents

Item #	Quantity Reqd.	Description
1		

# Additional Items Required For Installation

Item #	Quantity Reqd.	Description
1		

#### Conflicts

None

#### **Recommended Tools**

Personal & Vehicle	Notes
Protection	
None	
Special Tools	Notes
Squeegee	4" (3M <sup>TM</sup> Gold) or
	4" (3M <sup>TM</sup> Silver)
Low Friction Sleeve	3M SA-1 (OPTIONAL)
Surface Thermometer	Infrared Non-contact
Heat Gun	Master Heat Gun HG-301A
	or equivalent
Installation Tools	Notes
Lint Free Rags	
Spray Bottle	For wetting agent
Special Chemicals	Notes
Cleaner	VDC approved cleaner and
	cleaning method
Wetting Agent	Johnson's Baby Shampoo
Note: Solution depends upon	mixed in one liter of water:
ambient temperature of the	At 65°F add 2 ml. shampoo
part and the vehicle surface. If it is difficult to remove	At 70°F add 3 ml. shampoo
bubbles with a squeegee, add	At 80°F add 3.5 ml shampoo
	At 90°F add 4 ml. shampoo
one more ml. of shampoo.	· · · · · · · · · · · · · · · · · · ·

## **General Applicability**

MY19 and newer ES/ESh vehicles


## **Recommended Sequence of Application**


Item #	Accessory
1	

Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		

### Legend





Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.


These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-


- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).


Please see your Lexus dealer for a copy of this document.


\*Mandatory












9



Look For:
Look for bubbles, loose and lifting edges.
With light pressure rub hand over top of part and if crackling sound occurs, re- squeegee. If bubbles cannot be worked out to the nearest edge, replace the part.
Part must be centered within bumper +/-3 mm.
Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMS Accessory Quality Shipping Standard.)