

Part Number: PT944-24150**Kit Contents**

Item #	Quantity Req'd.	Description
1	2	Inner LED Scuff
2	2	Outer Scuff
3	1	Hardware Bag

Hardware Bag Contents

Item #	Quantity Req'd.	Description
1	15	20 cm Wire Tie
2	4	3M Scotchlok
3	6	Foam Tape

Additional Items Required For Installation

Item #	Quantity Req'd.	Description
1		
2		
3		

Conflicts

--

Recommended Tools

Personal & Vehicle Protection	Notes
Safety Glasses	
Safety Gloves	Optional
Vehicle Protection	Blankets, Parts Boxes
Special Tools	Notes
Installation Tools	Notes
Phillips Screwdriver	
Nylon Panel Removal Tool	e.g. Panel Pry Tool #1
Metal 90-Degree Pick	
Side Cutters	
Pliers	
Needle Nose Pliers	
Ratchet & Socket	10mm
Torque Wrench	5.4 N-m (48 in-lbs)
Special Chemicals	Notes
Cleaner	VDC Approved Cleaner

General Applicability

--


Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

*Mandatory

Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Req'd.	Description
1		
2		
3		

Legend**STOP:** Damage to the vehicle may occur. Do not proceed until process has been complied with.**OPERATOR SAFETY:** Use caution to avoid risk of injury.**CAUTION:** A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.**TOOLS & EQUIPMENT:** Used in Figures calls out the specific tools and equipment recommended for this process.**REVISION MARK:** This mark highlights a change in installation with respect to previous issue.**SAFETY TORQUE:** This mark indicates that torque is related to safety.

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Lexus dealer for a copy of this document.

1. Disassemble the Vehicle.



(a) Set the parking brake.


(b) Lower the windows and move the seats to the full rearmost position.

(c) Remove the negative battery cable (Fig. 1-1).

(1) Protect the fender before starting.




(2) Do not touch the positive terminal with any tool when removing the cable.



(d) Cover the seat with a blanket (Fig. 1-2).

(e) Place masking tape on the front doorsill.



(f) Use a nylon panel removal tool to disengage the four (4) clips and carefully lift the doorsill trim piece (Fig. 1-3).

(g) Remove the masking tape and ensure no tape residue remains.

(h) Remove the front driver side inner door sill trim.

(1) Hold the weather strip at the clip locations (Fig. 1-4).

(2) Dislodge the four (4) clips (Fig. 1-4).

⚠ CAUTION: Do not bend or break the bottom clips at either end of the sill trim.

(i) Apply the parking brake to ease access to the kick panel.



- (j) Pull to disengage the four (4) clips while holding the weather strip at the clip locations to remove the kick panel trim piece from the vehicle (Fig. 1-5 and Fig. 1-6). Rotate the part, with the finished surface going into the cabin, as it is removed to avoid breaking the clips.


⚠ NOTE: Do not remove the weather strip. Hold the weather strip at the clip area while pulling back the kick panel.




- (k) Squeeze the clip together with needle nose pliers and pull the kick panel towards the interior of the vehicle to disengage the carpeted kick panel (Fig. 1-7 and Fig. 1-8).
- (l) Repeat Step 1(c) through Step 1(j) on the passenger side of the vehicle.




- (m) Remove the two screws and release the two clips from the driver side under dash trim panel (Fig. 1-9).



- (n) Pull down the driver side under dash trim panel to expose the foot light connector and disengage it (Fig. 1-10).
- (o) Place masking tape along the bottom edge of the passenger side knee panel.



- (p) Use a nylon removal tool to release the 4 clips on the under dash trim panel (Fig. 1-11).




- (q) Lower the panel to expose the foot light connector. Disconnect it and remove the panel (Fig. 1-12).
- (r) Remove the masking tape and ensure no tape residue remains.

2. Install the Driver Side Door Sill.

- (a) Locate the 20 pin connector on the driver side kick panel connector block (Fig. 2-1).




- (b) Disconnect the connector and locate the violet wire (CTY light [-], pin 5) (Fig. 2-2).




- (c) Connect the violet wire from the door sill to the violet wire on the vehicle connector with a Scotchlok (Fig. 2-3).





NOTE: Refer to Fig. 2-4 for instructions on proper Scotchlok installation.

- (d) Use pliers to push down the metal tab to splice the wires. Make sure both wires are spliced correctly (Fig. 2-4).
- (e) Snap the plastic cover in place by hand.
- (f) Cut a piece of foam tape in half and wrap it over the wire tap.
- (g) Reattach the connector to the connector block (Fig. 2-5).




- (h) Locate the blue wire (B[+], pin 1) on the driver side foot lamp connector (Fig. 2-6).
- (i) Route the wire above the hood latch cable (see Fig. 2-8) and connect the blue wire from the door sill to the foot lamp with a Scotchlok (Fig. 2-6).




(j) Apply foam tape over the fuse holder and the Scotchlock (Fig. 2-7).

NOTE: Do not cover the fuse holder cap. A strip of foam tape may be cut in half, if desired.




(k) Apply two wire ties (Fig. 2-8).


CAUTION: Make sure the wire is routed above the hood latch cable. Do not attach the wire to the hood latch cable.




(l) Route the door sill wire harness along the OE wire harness toward the bottom of the vehicle and secure the fuse holder with two wire ties (Fig. 2-9).



- (m) Route the door sill wire harness down along the OE wire harness and secure it with two wire ties (Fig. 2-10).



- (n) Route the door sill wire harness along the OE floor wire harness and secure it with one wire tie (Fig. 2-11).



- (o) Route the door sill wire harness along the OE floor wire harness and secure it with one wire tie (Fig. 2-14).

3. Install the Passenger Side Door Sill.

- (a) Locate the 64 pin connector behind the passenger side kick panel (Fig. 3-1).



Fig. 3-1

- (b) Push the locking tab up and pull the black lock mechanism out to remove the connector from the connector block (Fig. 3-2).





Fig. 3-2

- (c) Remove the black lock mechanism (Fig. 3-3).



Fig. 3-3



- (d) Locate the green wire (CTY[-], pin 6) (Fig. 3-4).



- (e) Connect the green wire from the door sill to the green wire on the vehicle connector with a Scotchlok (Fig. 3-5).
- (f) Use pliers to push down the metal tab to splice the wires. Make sure both wires are spliced correctly.
- (g) Snap the plastic cover in place by hand.
- (h) Apply foam tape over the wire tap.



- (i) Reattach the black lock mechanism and reconnect it to the connector block (Fig. 3-6).

⚠ CAUTION: Make sure the connector lock engages securely.




- (j) Locate the blue wire (B[+], pin 1) on the driver side foot lamp connector (Fig. 3-7).



- (k) Connect the blue wire from the door sill to the foot lamp with a Scotchlok (Fig. 3-8).




- (l) Apply foam tape over the Scotchlock (Fig. 3-9).




(m) Apply foam tape over the fuse holder (Fig. 3-10).


⚠ NOTE: Do not cover the fuse holder cap. A strip of foam tape may be cut in half, if desired.





(n) Tie the blue wire to the foot lamp wire harness with two wire ties (Fig. 3-11).



(o) Route the door sill wire harness down along the OE wire harness and secure it with three wire ties (Fig. 3-12 and Fig. 3-13).





- (p) Route the door sill wire harness along the OE floor wire harness and secure it with two wire ties (Fig. 3-14 and Fig. 3-15).

4. Perform an In-Process Functional Test.

- (a) Temporarily reconnect the battery negative cable and install the DCC cut fuse if necessary.




NOTE: Make sure all doors and the trunk are closed before proceeding with the function test.

- (b) Confirm that the illuminated doorsills function properly.
- (1) Door open – Front door sills are illuminated (Fig. 4-1).
 - (2) Door closed (or the door switch is pressed) – Front door sill illumination goes out.
- (c) Disconnect the battery negative cable and remove the DCC cut fuse if it was installed in Step 4(a).


5. Reassemble the Vehicle.


- (a) Reinstall the lower instrument panel covers. Make sure all hooks are snapped in and all screws are fastened.
- (b) Assemble the cowl panels. Make sure the clips are snapped in properly (Fig. 5-1).



- (c) Install the door sills. Make sure the door sills are properly snapped down in place and that no lifting occurs or uneven gaps exist around the edges (Fig. 5-2).





 **CAUTION:** Ensure the clips at the left and right sides are engaged fully.

 **CAUTION:** Ensure no wire pinch points exist between the sill and the body.

6. Reconnect the Battery.

- (a) Reconnect the battery negative cable.

 **Torque: 5.4 N-m (48 lbf-in)**

 (b) Be careful not to touch the positive battery terminal with any tools.

- (c) Clean up and remove any trash.

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:	Look For:
<p><u>Accessory Function Checks</u></p> <p><input type="checkbox"/> Proper operation of the Illuminated Door Sills</p>	<p>Door open – Front door sills are illuminated.</p> <p>Door closed – Front door sills are not illuminated</p>
<p><u>Vehicle Function Checks</u></p> <p><input type="checkbox"/> Dome light</p> <p><input type="checkbox"/> Foot well lighting</p> <p><input type="checkbox"/> Door courtesy lights</p> <p><input type="checkbox"/> Parking brake light</p> <p><input type="checkbox"/> Tail lights, brake lights, reverse lights, rear turn signals, hazard lights, license plate light</p> <p><input type="checkbox"/> High beam dash light</p> <p><input type="checkbox"/> Horn</p> <p><input type="checkbox"/> Power door locks, power mirrors, power windows</p> <p><input type="checkbox"/> 12V/cigarette outlet</p> <p><input type="checkbox"/> Dimmer switch</p> <p><input type="checkbox"/> Radio reception</p> <p><input type="checkbox"/> HVAC</p> <p><input type="checkbox"/> Steering wheel controls</p> <p><input type="checkbox"/> Trunk release</p> <p><input type="checkbox"/> Smart key functions</p>	<p>Dome light operates properly</p> <p>Foot well lighting operates properly</p> <p>Front door courtesy lights operate normally</p> <p>Apply the parking brake and confirm the brake dash light comes on</p> <p>All rear lights operate normally</p> <p>Turn on the headlights, activate the high beams and verify the high beam dash light comes on</p> <p>Horn operates properly</p> <p>Power door locks, mirrors, and windows function normally</p> <p>Outlet operates properly</p> <p>Dimmer switch operates properly</p> <p>Radio AM/FM reception operates normally</p> <p>HVAC system operates properly</p> <p>Steering wheel controls operate properly</p> <p>Trunk release operates normally</p> <p>Smart key functions operate normally</p>
<p><u>Vehicle Appearance Check</u></p> <p><input type="checkbox"/> After accessory installation and removal of protective cover(s), perform a visual inspection.</p>	<p>Ensure no damage (including scuffs and scratches) was caused during the installation process.</p> <p>(For PPO installations, refer to TMS Accessory Quality Shipping Standard.)</p>